

Alphabetical index

A

A/C

Air conditioning filter 781

Front automatic air

conditioning system 402

Rear air conditioning system 416

ABS (Anti-lock Brake System) 315

Function 315

Warning light 806

Adaptive Front-lighting System

(AFS) 239

AFS (Adaptive Front-lighting

System) 239

Air conditioning filter 781

Air conditioning system

Air conditioning filter 781

Front automatic air conditioning

system 402

Rear air conditioning system 416

Airbags 44

Airbag operating conditions 52

Airbag precautions

for your child 47

Airbag warning light 806

Correct driving posture 36

Curtain shield airbag

operating conditions 53

Curtain shield airbag

precautions 47

Front passenger occupant

classification system 57

General airbag precautions 47

Locations of airbags 44

Modification and disposal

of airbags 51

Side airbag operating

conditions 53

Side airbag precautions 47

Side and curtain shield airbags

operating conditions 53

Side and curtain shield airbags

precautions 47

SRS airbags 44

Alarm	
Alarm.....	91
Warning buzzer	805, 815
Anchor brackets.....	67, 68
Antennas (smart access system	
with push-button start).....	130
Anti-lock Brake System (ABS).....	315
Function	315
Warning light	806
Approach warning.....	268
Armrest	705
Ashtrays.....	691
Assist grips	715
Audio input.....	530
Audio system.....	425
Audio input.....	530
Audio visual input	600
AUX port/	
USB port.....	512, 522, 530
A/V input port.....	600
Bluetooth® audio.....	499
CD/DVD player.....	467
CD/DVD player information.....	487
DVD video.....	475
iPod.....	520
MP3/WMA disc	469
Optimal use	532
Portable music player.....	530
Radio	449
Rear seat audio controls	534
Rear seat entertainment	
system	541
Steering wheel audio switch	538
USB memory	510
Audio visual input.....	600

Automatic headlight leveling	
system.....	240
Automatic High Beam.....	242
Automatic light control system	238
AUX port	530
Auxiliary boxes	683
A/V input port.....	600

B

Back-up lights	
Replacing light bulbs	793
Battery (12-volt battery)	762
If the 12-volt battery is	
discharged.....	836
Preparing and checking before	
winter.....	352
Warning light.....	806
Battery (traction battery)	82
Blind Spot Monitor (BSM)	334
Bluetooth®	
Audio system.....	499
Hands-free system	
(for cellular phone)	605
Brake	
Brake Hold	235
Fluid	760
Parking brake	232
Regenerative braking.....	79
Warning light.....	805, 807

Brake assist 315
 Brake Hold 235
 Break-in tips 203
 Brightness control
 Instrument panel light control 101
 BSM (Blind Spot Monitor) 334

C

Card key 122
 Care 730, 734
 Aluminum wheels 731
 Exterior 730
 Interior 734
 Seat belts 735
 Cargo capacity 217
 Cargo hooks 686
 Cargo net 686
 Caution label 82
 CD player 467
 Chains 354
 Child restraint system 63
 Booster seats, definition 63
 Booster seats, installation 72
 Convertible seats, definition 63
 Convertible seats, installation 70
 Front passenger occupant
 classification system 57
 Infant seats, definition 63
 Infant seats, installation 70
 Installing CRS
 with LATCH anchors 69
 Installing CRS with seat belts 70
 Installing CRS
 with top tether strap 73

Child safety 62
 12-volt battery
 precautions 764, 839
 Airbag precautions 47
 Child restraint system 63
 Climate control seat
 precautions 704
 Heated steering wheel
 precautions 699
 How your child should wear
 the seat belt 39, 40
 Installing child restraints 67
 Moon roof precautions 200
 Power window lock switch 194
 Power window precautions 196
 Rear door child-protectors 147
 Removed electronic
 key battery precautions 785
 Seat belt comfort guide 39
 Seat belt extender precautions 43
 Seat belt precautions 66
 Trunk precautions 153
 Child-protectors 147
 Cigarette lighter 692
 Cleaning 730, 734
 Aluminum wheels 731
 Exterior 730
 Interior 734
 Seat belts 735
 Climate control seat 700
 Climate control seat filter 703
 Clock 690
 Clock light 671
 Coat hooks 714
 Coin holder 678
 Condenser 759

Console box	681
Consumption screen	117
Coolant	757
Capacity	853
Checking	757
Preparing and checking before	
winter	352
Cooling system	757
Engine overheating	840
Hybrid system overheating	840
Cruise control	
Cruise control	257
Dynamic radar cruise control	
with full-speed range	261
Cup holders	679
Curtain shield airbags	45
Customizable features	874

D

Daytime running light system	240
Defogger	
Front windshield	407
Outside rear view mirrors	423
Rear window	423
Differential	
Front differential	854
Rear differential	855
Dimensions	848
Dinghy towing	219

Display

Dynamic radar cruise control	
with full-speed range	261
LKA (Lane-Keeping Assist)	281
Multi-information display	105
Remote Touch screen	360
Trip information	106
Warning message	815
Do-it-yourself maintenance	745
Door courtesy lights	671
Door lock	
Doors	146
Smart access system with	
push-button start	127
Wireless remote control	142
Door pockets	678
Doors	146
Automatic door locking	
and unlocking system	148
Door glasses	194
Door lock	146
Open door warning buzzer	132
Open door warning light	808
Outside rear view mirrors	190
Rear door child-protector	147

Driver's seat position memory	177
Driving.....	202
Break-in tips	203
Correct driving posture	36
Driving mode select switch	309
Hybrid vehicle driving tips.....	350
Procedures	202
Winter drive tips.....	352
DVD player.....	467, 475
Dynamic radar cruise control	
with full-speed range.....	261
Function	261

E

Eco drive mode.....	309
EDR (Event data recorder).....	11
Electric motor (traction motor)	77
Electric Power Steering (EPS)	316
Function	316
Warning light	806
Electronic key	122
If the electronic key does not	
operate properly.....	833
Replacing the battery.....	784
Electronically modulated air	
suspension.....	313
Emergency flashers.....	796

Emergency, in case of

If the 12-volt battery is	
discharged.....	836
If the electronic key	
does not operate properly.....	833
If the hybrid system	
will not start	828
If the parking brake	
cannot be released	831
If the shift lever	
cannot be shifted from P	830
If the warning buzzer sounds.....	805
If the warning light turns on.....	805
If the warning message	
is displayed.....	815
If you have a flat tire.....	818
If you think something	
is wrong	804
If your vehicle becomes	
stuck.....	845
If your vehicle has to be	
stopped in an emergency.....	797
If your vehicle needs	
to be towed.....	798
If your vehicle overheats.....	840

Energy monitor 114

Engine

- Accessory mode 221
- Compartment 751
- Engine switch 220
- Hood 748
- How to start the hybrid system... 220
- Identification number 849
- If the hybrid system
 - will not start 828
- Ignition switch
 - (power switch) 220
- Overheating 840
- Power switch 220

Engine compartment cover 752

Engine coolant 757

- Capacity 853
- Checking 757
- Preparing and checking
 - before winter 352

Engine coolant temperature

- gauge 99

Engine oil 754

- Capacity 851
- Checking 754
- Preparing and checking
 - before winter 352

Engine switch 220

EPS

- (Electric Power Steering) 316
- Function 316
- Warning light 806

EV drive mode 225

Event data recorder (EDR) 11

F

First-aid kit storage belt 687

Flat tire 818

Floor mats 34

Fluid

- Brake 855
- Hybrid transmission 854
- Washer 761

Fog lights 247

- Replacing light bulbs 793
- Switch 247

Footwell light 671

Front automatic air conditioning

- system 402

Front fog lights 247

- Replacing light bulbs 793
- Switch 247

Front passenger occupant

- classification system 57

GH

Heaters

- Front automatic air conditioning system 402
- Heated steering wheel 698
- Outside rear view mirrors 423
- Rear air conditioning system 416

Height control

- Electronically modulated air suspension 313

High-voltage components 82

Hill-start assist control 315

Hood 748

- Open 748

Hooks

- Cargo hooks 686
- Coat hooks 714
- Retaining hooks (floor mat) 34
- Shopping bag hooks 686

Horn 237

Hybrid battery (traction battery) 82

Hybrid battery (traction battery)

- air vents 83

Hybrid system 77

- Emergency shut off system 83
- Energy monitor/ consumption screen 113
- EV drive mode 225
- High voltage components 82
- Hybrid System Indicator 103
- Hybrid system precautions 82
- Hybrid vehicle driving tips 350
- If the hybrid system will not start 828
- Overheating 840
- Power (ignition) switch 220
- Starting the hybrid system 220

Vehicle proximity notification

- system 78

Hybrid System Indicator 103

Hybrid transmission 227

- If the shift lever cannot be shifted from P 830
- S mode 228

I

I/M test 744

Identification 849

- Engine 849
- Vehicle 849

Ignition switch (power switch) 220

Illuminated entry system 674

Immobilizer system 89

Indicators 96

Initialization

- Maintenance 738
- Moon roof 199
- Power windows 195
- Tire pressure warning system 767

Initiators (tire pressure warning system) 774

Inside door handle lights 671

Inside rear view mirror 188

Instrument panel light control 101

Instrument panel ornament

- lights 671

Interior lights 672

- Front interior light 672
- Rear interior light 672
- Wattage 858

Interior lights list 671

Intuitive parking assist 287

- Function 287

J

Jack	
Positioning a floor jack	749
Vehicle-equipped jack	819
Jack handle	819
Jam protection function	
Moon roof	198
Power trunk opener	
and closer	152
Power windows	195
Rear door sunshade	712

K

Keyless entry	127
Smart access system	
with push-button start	127
Wireless remote control	142
Keys	122
Electronic key	122
Engine switch	220
If the electronic key	
does not operate properly	833
If you lose your keys	124, 126
Key number plate	122
Keyless entry	127, 142
Mechanical key	123
Power switch	220
Replacing the battery	784
Warning buzzer	132
Wireless remote control key	142
Knee airbags	44

L

Lane-keeping assist (LKA)	277
Operation	279
Language	
(multi-information display)	109
LATCH anchors	69
Lever	
Auxiliary catch lever	748
Hood lock release lever	748
Internal trunk release lever	152
Shift lever	227
Turn signal lever	231
Wiper lever	248
Lexus Climate Concierge	401
Lexus Enform *	
Lexus night view	345
License plate lights	238
Light switch	238
Replacing light bulbs	793
Welcome light	
illumination control	128
Light bulbs	
Replacing	793
Wattage	858

M

Lights

Automatic High Beam system	242
Fog light switch	247
Headlight switch	238
Illuminated entry system	674
Interior lights	672
Interior lights list	671
Personal lights	673
Replacing light bulbs	793
Trunk light	152
Turn signal lever	231
Vanity lights	688
Wattage	858
Welcome light illumination control	128
LKA (Lane-Keeping Assist)	277
Operation	279
Load capacity	217
Lock steering column	222
Luggage security system	151

Maintenance

Do-it-yourself maintenance	745
General maintenance	740
Maintenance requirements	737
Malfunction indicator lamp	806
Master warning light	808
Meter	99
Indicators	96
Instrument panel light control	101
Meters	99
Multi-information display	105
Warning lights	95
Micro dust and pollen filter	410
Mirrors	
Inside rear view mirror	188
Outside rear view mirror defoggers	423
Outside rear view mirrors	190
Vanity mirrors	688
Moon roof	197
Door lock linked moon roof operation	198
Jam protection function	198
Operation	197
MP3 disc	469

*: Refer to the "Navigation System Owner's Manual".

Multi-information display 105
 Dynamic radar cruise control
 with full-speed range 261
 Energy monitor 114
 Lane-Keeping Assist 281
 Language 109
 Switching the display 106
 Trip information 106
 Warning message 815

N

Navigation system* 8
 Noise from under vehicle 8

O

Odometer 99
 Oil
 Engine oil 851
 Front differential oil 854
 Rear differential oil 855
 Opener
 Fuel filler door 255
 Hood 748
 Trunk 150
 Outer foot lights
 Location 671
 Replacing light bulbs 793

Outside rear view mirrors 190
 Adjusting and folding 190
 BSM (Blind Spot Monitor) 334
 Linked mirror function
 when reversing 192
 Mirror position memory 177
 Outside rear view
 mirror defoggers 423
 Outside temperature display 99
 Overheating 840

P

Parking assist sensors
 (intuitive parking assist) 287
 Parking brake 232
 If the parking brake
 cannot be released 831
 Operation 232
 Parking brake engaged
 warning buzzer 234
 Parking lights 238
 Light switch 238
 Replacing light bulbs 793
 Welcome light
 illumination control 128

PCS (Pre-Collision System).....	322
Function	322
Pre-collision braking off switch...	324
Warning light	807
Pelvic support seat with seat	
vibrator	169
Penlight.....	819
Personal lights.....	673
Front personal light	673
Rear personal light	673
Wattage.....	858
Power control unit	82
Power control unit coolant.....	757
Capacity	853
Checking.....	757
Preparing and checking before	
winter.....	352
Power easy access system	160
Power outlets	694
Power steering (Electric Power	
Steering system).....	316
Warning light	806
Power switch.....	220
Power trunk opener and closer	150
Power windows.....	194
Door lock linked	
window operation.....	196
Jam protection function.....	195
Operation	194
Window lock switch.....	194

Pre-Collision System (PCS).....	322
Function.....	322
Pre-collision braking off	
switch	324
Warning light.....	807

R

Radiator.....	759
Radio	449
RBDS (Radio Broadcast	
Data Systems)	452
Rear air conditioning system.....	416
Rear door sunshades.....	711
Rear seat	
Adjustment.....	164
Climate control seats	700
Seat position memory.....	182
Rear seat entertainment system	541
Rear seat relaxation system.....	171
Rear side marker lights.....	238
Light switch.....	238
Replacing light bulbs	793
Welcome light	
illumination control.....	128
Rear sunshade.....	708
Operation.....	708
Reverse operation feature	709

*: Refer to the "Navigation System Owner's Manual".

Rear turn signal lights	231
Replacing light bulbs	793
Turn signal lever	231
Rear view mirror	
Inside rear view mirror	188
Outside rear view mirrors	190
Rear view monitor system	298
Rear window defoggers	423
Refueling	253
Capacity	850
Fuel types	253, 850
If the fuel filler door	
cannot be opened	256
Opening the fuel tank cap	255
Regenerative braking	79
Remote Touch	358
Remote Touch screen	360
Replacing	
Electronic key battery	784
Fuses	786
Light bulbs	793
Tires	818
Reporting safety defects	
for U.S. owners	890
Reset the maintenance data	738
Retractable table	706
Road accident cautions	86

S

Safety Connect	722
Seat belt reminder light	808
Seat belts	38
Adjusting the seat belt	39
Automatic locking retractor	
(ALR)	40
Child restraint system	
installation	70
Cleaning and maintaining	
the seat belt	735
Emergency locking retractor	
(ELR)	40
How to wear your seat belt	38
How your child should wear	
the seat belt	40
Pre-collision seat belts	40
Pregnant women, proper	
seat belt use	41
Reminder light and buzzer	808
Seat belt extender	40
Seat belt pretensioners	39
SRS warning light	806
Seat cushion airbag	45
Seat position memory	177, 182
Seating capacity	217

Seats	157, 164	Shift lever	227
Adjustment.....	157, 164	Hybrid transmission	227
Adjustment precautions	162, 175	If the shift lever	
Child seats/child restraint		cannot be shifted from P	830
system installation.....	67	Shift lever light	671
Cleaning	734	Shift lock system	830
Climate control seat	700	Shopping bag hooks	686
Driving position memory	177	Side airbags	45
Head restraints	184	Side marker lights	238
Pelvic support seat with seat		Light switch.....	238
vibrator	169	Replacing light bulbs	793
Power easy access system	160	Welcome light illumination	
Properly sitting in the seat	36	control.....	128
Rear seat position memory	182	Side mirrors	190
Rear seat relaxation system	171	Adjusting and folding	190
Seat position memory	177, 182	BSM (Blind spot monitor)	334
Sensor		Linked mirror function	
Automatic headlight system	240	when reversing.....	192
Automatic High Beam		Mirror position memory	177
system	246	Side turn signal lights	231
Camera sensors	325	Replacing light bulbs	793
Driver monitor sensor	325	Turn signal lever	231
Inside rear view mirror	189	Smart access system	
Intuitive parking assist	287	with push-button start	127
Lexus night view	349	Antenna location.....	130
LKA (Lane-Keeping Assist)	277	Entry functions	127
Radar sensor	271, 324, 338	Starting the hybrid system.....	220
Rain-sensing windshield		Snow mode	229
wipers	250	Snow tires	355
Service plug	82		
Service reminder indicators	94		

Spare tire.....	818
Inflation pressure.....	856
Storage location.....	819
Spark plug.....	853
Specifications.....	848
Speedometer.....	99
Sport mode.....	309
Steering lock.....	222
Column lock release.....	222
Steering wheel.....	187
Adjustment.....	187
Audio switches.....	538
Heated steering wheel.....	698
Power easy access system.....	160
Steering wheel position memory.....	177
Stop lights	
Replacing light bulbs.....	793
Storage feature.....	675
Stuck	
If the vehicle becomes stuck.....	845
Sun shade	
Rear.....	708
Rear door.....	711
Roof.....	198
Sun visors.....	688

Switches

Audio remote control switches.....	538
Automatic High Beam switch.....	242
Brake hold switch.....	235
BSM (Blind spot monitor) main switch.....	334
Climate control seat switches.....	700
Cruise control switch.....	257
"DISP" button.....	106
Door lock switches.....	146
Driving mode select switch.....	309
Driving position memory switches.....	177
Dynamic radar cruise control with full-speed range.....	261
Emergency flashers switch.....	796
EV drive mode switch.....	225
Fog light switch.....	247
Garage door opener switches.....	716
Headlight cleaner switch.....	252
Heated steering wheel switch.....	698
Ignition switch.....	220
Intuitive parking assist.....	287
Lexus night view switch.....	345
Light switch.....	238
LKA (Lane-Keeping Assist) switch.....	279
Moon roof switches.....	197
Outside rear view mirror switches.....	190
Parking brake switches.....	232
Power door lock switch.....	146
Power switch.....	220

T

Power trunk lid.....	150
Power window switches	194
Pre-collision braking off switch....	324
Rear door sunshade switch.....	711
Rear seat position memory.....	182
Rear sunshade switch.....	708
Rear window and outside rear view mirror defoggers switch.....	423
Snow mode switch.....	229
"SOS" button.....	722
Talk switch.....	391
Telephone switches.....	606
Tilt and telescopic steering control switch	187
Tire pressure warning reset switch.....	768
Trunk closer switch.....	151
Trunk opener switch	150
Trunk opener main switch.....	151
Vehicle-to-vehicle distance button	264
VSC OFF switch	317
Window lock switch.....	194
Windshield wipers and washer switch	248

Tachometer	99
Tail lights	238
Light switch.....	238
Replacing light bulbs	793
Welcome light illumination control.....	128
Talk switch.....	391
Telephone switches.....	606
Theft deterrent system	
Alarm	91
Immobilizer system.....	89
Tire inflation pressure.....	776
Maintenance data.....	856
Tire inflation pressure display function.....	108
Warning light.....	809
Tire information	862
Glossary.....	869
Size	865
Tire identification number	864
Uniform Tire Quality Grading	867
Tire pressure warning system.....	767
Function.....	767
Initializing	767
Installing tire pressure warning valves and transmitters.....	767
Registering ID codes.....	769
Tire pressure warning reset switch	768
Warning light.....	809

Tires	766	Trip information	106
Chains.....	354	Trip meters	99
Checking.....	766	Trunk	150
If you have a flat tire	818	Internal trunk release lever	152
Inflation pressure.....	856	Jam protection function.....	152
Information	862	Luggage security system.....	151
Replacing	818	Power trunk opener	
Rotating tires	766	and closer	150
Size.....	856	Smart access system	
Snow tires	355	with push-button start.....	129
Spare tire.....	818	Trunk closer switch.....	151
Tire inflation pressure display		Trunk easy closer	152
function.....	108	Trunk features.....	686
Tire pressure warning system	767	Trunk grip	151
Warning light	809	Trunk lid light	152
Tools	819	Trunk light.....	152
Top tether strap	73	Trunk opener main switch	151
Total load capacity	217	Trunk opener switch	150
Towing		Wireless remote control.....	142
Dinghy towing	219	Trunk light	
Emergency towing	798	Trunk lid light	152
Towing eyelet.....	799	Trunk light.....	152
Trailer towing	218	Wattage	858
TRAC (Traction Control)	315	Turn signal lights	231
Traction battery (hybrid battery)	82	Replacing light bulbs	793
Traction motor (electric motor)	77	Turn signal lever	231
Trailer towing	218		
Transmission	227		
Driving mode select switch	309		
Hybrid transmission.....	227		
If the shift lever cannot be			
shifted from P	830		
S mode.....	228		

U

USB port 512, 522

V

Vanity lights
 Vanity lights 688
 Wattage 858
 Vanity mirrors 688
 Variable Gear Ratio Steering
 (VGRS) 315
 Function 315
 VDIM (Vehicle Dynamics
 Integrated Management) 316
 Vehicle data recordings 10
 Vehicle Dynamics Integrated
 Management (VDIM) 316
 Vehicle identification number 849
 Vehicle proximity notification
 system 78
 Vehicle Stability Control
 (VSC) 315
 VGRS (Variable Gear Ratio
 Steering) 315
 Function 315
 Voice command system 391
 VSC
 (Vehicle Stability Control) 315

W

Warning buzzers
 Approach warning 268
 Brake system 805
 Downshifting 230
 Intuitive parking assist 287
 Key reminder 132
 No-handed driving warning 282
 Open door 808
 Open moon roof 200
 Pre-collision braking 323
 Seat belt reminder 808
 Warning lights 95
 ABS 806
 Brake hold operated
 indicator 807
 Brake system 805, 807
 Charging system 806
 Electric power steering 806
 Low fuel level 808
 Malfunction indicator lamp 806
 Master warning light 808
 Open door 808
 Parking brake indicator 807
 Pre-collision system 807
 Seat belt reminder light 808
 Slip indicator 807
 SRS 806
 Tire pressure 809

Washer248
 Checking.....761
 Preparing and checking
 before winter352
 Switch.....248
 Washing and waxing.....730
 Weight
 Cargo capacity217
 Load limits.....217
 Weight.....848
 Welcome light illumination
 control.....128
 Wheels.....779
 Replacing wheels.....779
 Size.....856
 Window glasses194
 Window lock switch194
 Windows194
 Power windows194
 Rear window defogger423
 Windshield wiper de-icer424
 Windshield wipers248
 Winter driving tips.....352
 Wireless remote control key142
 Locking/Unlocking.....142
 Replacing the battery784
 WMA disc.....469

X

XM® Satellite Radio.....458

